

# JB Series Storage Racks

## Two Body Carrier With or Without Body Trays



JB000 Carrier shown without Body Trays

### JB Series Body Trays are Completely Removable with a Typical Fork-Type Lift

Designed for use with roll-in coolers, the JB100 carrier can hold two bodies on JC100 Body Trays.

### JB Series Standard Features

**Cart Saddle:** Fabricated of 14 gauge stainless steel with #4 satin finish, the saddle is completely welded with no overlapping seams or gaps. All exposed welds are ground smooth and grained to match a #4 satin finish.

**Cart Frame:** Material on the cart frame is 1-1/2" 11 gauge stainless steel tubing with all continuous bead weld with 1/8" radius bead.

**Casters:** Heavy-duty 5" diameter casters are provided with four wheel brakes and one swivel lock.

**Welds:** All welding is TIG type welding utilizing only stainless steel as a filler media. All weld fillets are approximately 1/8" diameter and are brushed clean removing any weld burrs or discoloration.

### JB Series Storage Racks

Description	Product No.
Carrier with Body Trays	JB100
Carrier without Body Trays	JB000



Shown with  
JC100 Body Trays  
JD710 Body Lift



Shown with  
JC100 Body Trays