

## JD715 Cadaver Lift

### Hand Crank Cadaver Lift



JD715 Hand Crank Lift

The JD715 is a modified JD710 with low profile legs to work with a DC100, JA500, JA600 or JA620 cart base. Folding lift legs retract for compact storage and movement through narrow doorways.

The cadaver lift is a free rolling lift that can be used alone or along with the JD400 Roller Pallet, JD500 Tray Lifting Bars or the JD600 Body Lift Bar.

#### Specifications:

- Height - stowed 78-1/2" (2 m)
- Length - stowed 29" (74 cm)
- Length - operating 59-1/2" - (1.5 m)
- Width - straddle base max inside 50" (1.27 m)
- Load height - min 2" (5.08 cm)
- Ground clearance - 3/8" (.95 cm)

#### JD715 Standard Features

**Support:** Base & Stabilizer are welded steel for extra support.

**Casters:** Non marring mold on Preforma Casters are durable and long lasting heavy-duty welded steel frame. Non marking casters easily roll over debris, curbs and soft or uneven ground without collection.

**Roller Systems:** Lightweight aluminum telescoping mast cross roller system is fabricated of extruded 6061-T6 aluminum with 4-point roller system between columns, which eliminates adjustment or servicing (patents pending).

**Cables:** Fabricated of 7/32 inch galvanized aircraft cable, complete with cable retaining system that prevents cable jumping.

**Breaks:** Safety breaks standard on all units.

**Finish:** Powder coated paint finish frame for long lasting and durable finish.

**Legs:** Low profile foldable legs for easy and compact storage.

**Capacity:** 1000 lbs.

**Product No. JD715**