

JD950 Series Cadaver Lift Conveyor Style - End Access JD955 Series Cadaver Lift Conveyor Style - Side Access

New & Improved



Mopec's JD900 and JD910 have been improved to become the JD950 and JD955. The rugged frame structure is now heavy-duty. Able to lift 750 pounds, the gray powder-coated finish features an integrated 12V hydraulic lifting unit for vertical adjustment and enables easy handling. The JD950/JD955 features the widest range of lift heights available in the market today and can be used for regular or bariatric (overweight) use. The vertical adjustment is controlled using an up/down push button switch. A key actuated switch prevents unauthorized operation and serves simultaneously as emergency off switch. Maintenance free drive battery ensures a constant power supply and is equipped with an electronic rapid charger. Built in scale (optional) allows easy and almost effortless weighing of the body. All four casters are swivel style with one lockable for directional control. Dual conveyor rollers are provided with stainless steel frame yielding an almost effortless loading and unloading. Front mounted ant-collision bumper. Overall shipping crate size is 95"W x 32"D x 40"H. Weight 880 lbs.



JD950 Cadaver Lift with the KH500 End opening Refrigerator. A control valve ensures even lowering at various loads. The raised height of the JD950/JD955 is 75-1/2", over 6 feet! Lowered height is 12-5/8".



Heavier reinforced frame



Optional scale JD970